




RPR-1650 Installation & Operation Handbook

Version 4.4.2

12.11.2010



CONTENTS

1. RPR-1650 and Security	3
1.1 Definition of text and symbols warning of dangerous situations.....	3
1.2 Security instructions for handling	3
1.3 Security instructions for service and maintenance	4
1.4 Security instructions for service personnel authorized by RPR Technologies AS	5
2. Unpacking the RPR-1650.....	6
3. Storing the RPR-1650	6
4. Preparing the Working Site	7
4.1 Electricity input	7
4.2 Water connection.....	7
4.3 Confining the work area.....	8
4.4 Work pattern procedure.....	8
5. How to Connect the RPR-1650.....	9
5.1 Overview of the connections.....	9
5.2 Assembly of the induction head on the handheld transformer.....	10
5.3 Connection of hose package(s) between main generator and condensator box	12
5.4 Water and electricity	13
5.4.1 Water connection.....	13
5.4.2 Electricity connection.....	14
6. Setting Parameters for Use of the RPR-1650.....	15
6.1 Program 1: Normal easy thin coatings	15
6.2 Program 2: Difficult thick coating.	16
7. Removal of Paint and Coatings	18
8. Transporting the RPR-1650	18
9. Check-List if the Machine Stops	19
10. Service and Maintenance	20
10.1 Daily control of hoses, cables and connections.....	20
10.2 Daily cleaning of RPR-1650	20
11. Dealers and Servicing.....	21
Appendix 1: RPR-1650 Voltage Output / Speed Program 1	23
Appendix 2: RPR-1650 Voltage Output / Speed Program 2.....	24
Appendix 3: Service Log.....	25

1. RPR-1650 and Security

Warning!

Before installing or operating the RPR-1650, or continuing with the other chapters in this handbook, you **MUST** read **Chapter 1. RPR-1650 and Security**. You should fully understand and follow the content of this chapter, and all the security warnings in this and other chapters. The security warnings are designed to prevent damage to the RPR-1650 equipment and to avoid serious injury or death to people operating or in contact with the equipment.

1.1 Definition of text and symbols warning of dangerous situations

Word/symbol	Definiton
 Careful!	Indicates a situation which, if not prevented, can be harmful to the equipment.
 Warning!	Indicates a potentially dangerous situation which, if not prevented, can lead to minor injuries to people operating or in contact with the equipment.
 Danger!	Indicates a potentially dangerous situation which, if not prevented, can lead to serious injury or death to people operating or in contact with the equipment.

1.2 Security instructions for handling

Danger!

- **Electrical Storms:** Never operate or attempt to repair the RPR-1650, or connect or disconnect cables in thunderstorms. Lightning strikes near equipment with electrical cables can lead to serious injury or death to people who are operating or in contact with the equipment.
- **Burns:** Do not touch the induction head with your bare skin or with electrical leading material. The induction equipment can in some cases be above 48 V AC and can result in serious burn injuries.
- **Metal:** The RPR-1650 creates a high-frequency magnetic field which causes any metal pieces in contact with the induction field to be heated. This can lead to serious burn injuries. Remove wristwatches, rings, jewellery and all other items which can conduct electricity from your hands and arms before operating the equipment.

! Danger!

- This machine produces a high-frequency magnetic field. People with **PACEMAKERS** can **NOT** operate this machine and must remain at least 1 meter (3 feet) from all parts of this electrical equipment.

! Warning!

- The RPR-1650 machine uses induction heat to remove paint, rust rubber and other coatings from steel substrates. The equipment must **NEVER** be used for any other purposes without prior permission from RPR Technologies AS.
- The RPR-1650 must be installed and operated only by personnel certified by RPR Technologies AS.
- RPR-1650 must only be used in temperatures between 0°C and 40°C.

Note where the emergency switch is placed on the machine:



1.3 Security instructions for service and maintenance

! Danger!

Only RPR authorized personnel are allowed to open the equipment. The main generator, including all connections, cables and electrical circuits, contains high-frequent electric power with condensators which store the electricity. This can lead to electrical shock which can cause serious injury or death to people coming in contact with the source.

- Installation of the main unit, maintenance and repair shall only be done by persons certified by RPR Technologies AS. This includes any work requiring opening the main generator or other equipment parts.
- Operation, maintenance or repair of the RPR-1650 by personnel who are not certified by RPR Technologies AS will void the equipment guarantee. Any work done by non-certified personnel is undertaken at your own risk.
- All instructions in this handbook are guidelines for authorised personnel only. The instructions and guidelines may be missing information. If in doubt you should contact RPR Technologies AS for the relevant information (contact details below).

1.4 Security instructions for service personnel authorized by RPR Technologies AS

- When working on the main generator, always wait 90 seconds after discharging the net power before touching anything inside the RPR-1650 or any equipment connected to the generator. If there is a fault with the RPR-1650 or any equipment connected to the generator, this waiting time must be extended to at least 5 minutes.
- The main generator shall under no circumstances be connected to the electrical supply when there is work to be done inside the unit.
- Before touching any components:
 - Measure the current (V), both AC and DC, between the component and the metal housing (ground), with a voltmeter.
 - No measurements should be above 20 V before touching the component.

Service/technical department RPR Technologies AS:

- Phone: +47 35 60 35 38
- E-mail: info@rprtech.com

2. Unpacking the RPR-1650

 **Warning!**

To avoid damage to the equipment, find a flat area where you can unpack the RPR-1650 safely and without danger of the equipment falling or being scratched when removing the wrapping from the different parts.

When you receive your new RPR-1650, you do as follows:

1. Before opening the boxes and unpacking your RPR-1650, you must check the boxes and pallets for outer damage. If you find any damage:
 - Describe the damage in writing.
 - Take pictures of the damage.
2. Do not destroy the boxes during unpacking. These can be re-used for transporting the RPR-1650 later.
3. Open the boxes and unpack the RPR-1650 and unwrap all the cables and different parts.
4. Check that all equipment and parts are free of damage and that they are in agreement with the enclosed packing list. If you find any damage:
 - Describe the damage in writing.
 - Take pictures of the damage.
5. Do not start assembly or connection before all parts are safely stored.
6. Store all boxes and wrapping for use in the later transport of the RPR-1650.

3. Storing the RPR-1650

The RPR-1650 must be stored in frost-free conditions, protected from rain and heavy wind. Indoor storage is recommended.

After heavy use, the RPR-1650 will have water inside all parts of the cooling system. This is the reason frost-free storage is required. If frost-free storage is not possible, the whole cooling system must be emptied of water by using dry air with temperature above freezing point. This must be completed before any hoses or induction heads are dismantled.

4. Preparing the Working Site

Before assembling and connecting the RPR-1650, you should prepare the working site.

4.1 Electricity input

- RPR-1650 should normally have **3 phases + ground, 400 V, 125 ampere.**
- Use of RPR-1650 in countries other than Norway: The RPR-1650 is built to tolerate electrical current from 360 V to 500 V. Output and working speeds may vary from normal in other countries.
NOTICE: The transformer inside of the machine needs to be reconnected to the same voltage as the main supply.
- If you do not have the correct electrical connections at the working site, then there is an adaptor for the RPR-1650 which can be connected to a cable to fit the local variety.

4.2 Water connection

- RPR-1650 needs fresh water for cooling, **minimum 4 bars / max 9 bars and 10 litres per minute.**
- Control the quality of the cooling water:
 - The water must be free from dirt and salt/chlorides as this can settle inside the induction head causing problems.
 - If the quality of the cooling water is no sufficient, you should use a standard filter.
- To avoid to low water flow:
 - The RPR-1650 will show a cooling water flow alarm when there is insufficient flow to operate safely, i.e. when using several cable packages (total length above 20 m) or when there is a big difference in height from the main unit to the working place.
 - If the alarm shows, use an external pump to obtain sufficient water flow.

4.3 Confining the work area

! Careful!


The RPR-1650 cables and hoses are not designed to be driven over by rolling material or to carry the weight of heavy material. If there is high activity in the working area, you should consider confining the working area so that the equipment not will be harmed.

4.4 Work pattern procedure

! Careful!

Overheating can cause damage to the steel of the treated surface and eventually lead to damage of the coating on the opposite side.

Overheating can occur if, for example, you overlap your movements on the treated surface too quickly, or by working in a wrong pattern. A method to avoid this problem is to sketch a mowing pattern on the surface to be treated before starting. Write a pattern on the surface to be treated which is a little bit smaller than the width of the induction head:



When you remove the coating (See section [7 Removal of paint and coatings, page 17](#)), you drag the induction head over each second marked-up field. This prevents the overheating on the edges. Then go back and take the other marked-up fields when the steel temperature has returned to normal.


5. How to Connect the RPR-1650



Careful!

Follow the instructions for connecting the RPR-1650 as described in this chapter to avoid damage on the equipment.

5.1 Overview of the connections



It is easy to connect the RPR-1650, but it is very important to follow some simple rules:

- **Do not connect the electricity or water supply** to the RPR-1650 until you have completed assembly of all cable packages, the condensator box, the handheld transformer unit and the induction head.
- All contacts are of the "mil" type and have an internal track you must get in the right position before entering the contact. Screw the locking ring with the clock all the way in, and at the same time push the contact in. This is to secure good contact on all contact pins.
- Push the water hose connections hard together so that the locking ring "clicks" back into the right position.
- The maximum length of cable package between the main generator and condensator box is 100 meters. Each cable package is 20 meters and has connections on each end for connection to the main generator and the condensator box. In total you can use five cable packages, and the length of the total package can be 20, 40, 60, 80, or 100 meters.


5.2 Assembly of the induction head on the handheld transformer

You choose the induction head based on the size of the work, the thickness and type of coating and the shape of the surface to be treated. Included with your new RPR-1650 there are two standard flat induction heads for treating flat surfaces. You can order induction heads for almost any surface and profile such as angles, pipes, studs, etc. Contact your local RPR representative about this.

How to assemble the induction head:

1. Take out the four screws with washers which sit in the end of the handheld transformer unit.
2. Screw the induction head tightly in place with a 6 mm Allen key:
 - Make sure that both O-rings are on place before mounting the induction head.
 - The cooper must be clean and free from foreign objects one both surfaces.
 - It is very important that all the washers are on the right place so that the induction head is tightly secured and has good contact with the handheld transformer unit.
 - Use the 6 mm Allen key and torque the screws by hand. Do not tighten too hard using extra equipment for this.
2. Assembling the white cable for the speed sensor:
 - Carefully pull the white cable with the sensor out from the handheld transformer unit.
 - Carefully push the cable into the track on the induction head.
 - Carefully tighten the screws which hold the sensor.




The completely assembled induction head should look like this:



Dismantling should be done in opposite direction.


Then place the cover over the connection bolts on the induction head.

Notice: The sensor cannot lie behind the cover. The Magnetic field will then damage the sensor. It needs to be mounted



5.3 Connection of hose package(s) between main generator and condensator box

A single hose package is 20 meters in length and has couplings on both ends for connection to the main generator and the condensator box. Dependant on your requirements, you can connect up to five hose packages so the total length can be 20, 40, 60, 80, or 100 meters.




The connections are the same on the main-generator, the condensator box and between each of the hose packages. The pictures below show the connections consisting of two water connections and one electrical contact:



Finished connectors:




5.4 Water and electricity



IMPORTANT! Do not connect the electricity or water supply to the RPR-1650 until you have completed assembly of all cable packages between the main generator and the condensator box and the induction head.

5.4.1 Water connection


1. Ensure that the water supply has the correct pressure and quality. See section [4.2 Water connection, page 7](#).
2. Connect the cooling water supply to RPR-1650 with 3/4" socket.




3. Connect hose for return water.
4. **IMPORTANT!** Check all hoses and connections for leakage.

5.4.2 Electricity connection

1. Ensure that the electricity supply has the correct parameters.
See section [4.1 Electricity input, page 7](#).
2. The main switch shall be in position **OFF**.



3. Connect the cable.




4. Turn the main switch to position **ON**.
Now you are ready to set the parameters for using the RPR-1650.
See next section.

6. Setting Parameters for Use of the RPR-1650

Before you start to remove paint and coatings, you must set the correct parameters for the desired result and progress. These parameters are dependent on the size of the inductor head and the type and thickness of the coating that is to be removed from the steel surface. There are two types of program that you can choose. One for thin coatings that will come off easily, and one for difficult and thick coatings. See sections [6.1 program 1](#) and [6.2 program 2](#).

A PLC-unit in the main generator controls the output in the induction head, dependant of the speed with which you move the induction head across the surface. The speed is measured with this sensor:



6.1 Program 1: Normal easy thin coatings


You must set the speed limit area with which you will move the induction head for removal of paint and coating. (meter/minute):

1. Choose Auto
2. Choose speed: Start with setting SPEED = 5 (look at illustration on page 18) which is the lowest energy input per square millimetre. You should avoid to overheating the steel.
3. Test the speed by moving the induction head over a limited area of the coating and check if the coating is loose.
 - Always make the test on a new spot so you don't heat the same area twice. (If you do the test incorrectly, you can damage the steel or the coating on opposite side!).
 - Take the SPEED setting down one step down at a time, until the effect causes the coating to become loose.
4. After setting the speed you have to wait to remove the coating in the test areas until the area is cooled down. (See section [4.4 Work pattern procedures, page 8](#))

5. Setting the maximum power: You only use this if you want to reduce the maximum power on the induction head, i.e. you are removing a coating on small areas, have a small induction head, or difficulties with the surroundings. You can make the adjustment by using the POWER button in relation to the specifications in Appendix 1 on page 23.

6.2 Program 2: Difficult thick coating.

1. Choose Auto
2. Login by F5 button. Choose the menu “LOWER LIMITS”. In this menu answer the question “ACTIVATE LOWER” with “YES”.
3. Start with POSITION 1= 40% (start point of voltage output) by pushing the F4 button. Start with setting SPEED = 5 by pushing the F1 button.
4. Test the POSITION setting by moving the induction head over a limited area of the coating and check if the coating is loose.
 - a. Always make the test on a new spot so you don't heat the same area twice. (If you do the test incorrectly, you can damage the steel or the coating on opposite side!).
 - b. Take the POSITION setting up one step at a time, until the effect causes the coating to become loose.
 - c. If the coating still doesn't become loose you need to take the SPEED setting down one step down at a time, until the effect causes the coating to become loose.
5. After setting the speed you have to wait to remove the coating in the test areas until the area is cooled down. (See section 4.4 Work pattern procedures, page 8)
6. In this program the power setting will always be 100%, see appendix 2 on page 24



Description of the buttons:

SPEED (Speed limit area): This has five preset maximum speeds. This will indicate how you should set the speed based on the type of coating and the size of the induction head. This means that you have an interval on the setting, i.e. 10 meter/minute which ensure that the RPR-1650 gives the needed power output based on the speed between 0 meter/minute to max power when at 10 meter/minute. See [Appendix 1 on page 23](#) for settings.

MAN/AUTO: With this button you can set whether you want to use the RPR-1650 with or without the power adjustment based on speed. You often use the manual setting when the coating is very thick (above 12 mm) and on small working pieces. **IMPORTANT!** On the manual setting there is a danger of overheating the steel or damage to the coating on opposite side.

RESET: If there is a warning in the display, the machine will trip. This button can be used for resetting the machine and removing the warning message in the display. If the warning is repeated after pushing reset, look at checklist in [Appendix 2](#) or contact your RPR distributor.

POWER: In some cases there is a need to use less than full power on the induction head, i.e. on small areas or with a small induction head or in difficult surroundings. This adjustment can be made with this button based on the specification in [Appendix 1 on page 23](#).

LCD-display: This displays all settings and warning codes for the RPR-1650, including power output and speed when in use. For warning codes see section [9. Check-List if the Machine Stops, page 19](#).

Up/down and Enter: These buttons should only be used by authorised personnel (coded) for changing parameters on the RPR-1650.

7. Removal of Paint and Coatings



It is very important that the steel is not overheated. This can happen if you move the induction head over the same area twice without time in between for the steel to be cooled down. Overheating can damage the steel or the coating on opposite side.

1. See that the following are done correctly:
Preparation: See section [4. Preparing the Working Site, page 7](#),
Connections: See section [5. How to Connect the RPR-1650, page 9](#).
Setting of Parameters: See section [6. Setting Parameters, page 15](#).
2. Check all hoses, cables and connections for leakage or damage. The LCD-display on the main generator will give warning messages and the RPR-1650 will stop when there is something wrong, but do the check anyway.
3. Use the sketched working pattern (See section [4.4 Work pattern procedure, page 8](#)) and drag the induction head over every second marked field so the steel not is overheated on the overlapping edges.
4. Sometimes the coating will not be loose enough to take away by hand, dependant on the generic type of coating and the age of the coating. When this occurs you should use a suitable scraper to remove the coating.
5. When every second marked field is finished you should go back and treat the fields in between. Ensure that the steel temperature is back to normal before doing this.

8. Transporting the RPR-1650

The RPR-1650 is easy to move with a forklift, crane or by rolling on its own wheels. For longer transport and change of working site, we recommend that you dismantle the cables, contacts and induction head.

Before longer transport, you should pack the RPR-1650 into the boxes as the machine was when it was new. The RPR-1650 does tolerate changes in weather and light bumps and shaking, but it is important that the machine does not get big bumps or heavy outer loads.

If you don't have the original boxes, pack the RPR-1650 to ensure it is well protected and stabilized.

9. Check-List if the Machine Stops

The following warning codes can appear on the display on the main generator. If the codes don't disappear when pushing button RESET, do the following:

Trip: One or several of the generator control systems for power, current and/or frequency is outside the generator's limits. If this problem persists after pushing reset, it should only be handled by authorized personnel.

Cooling Water Fault:

- Check for leakage or damage to hoses.
- Cooling water flow is too low, install a pump for extra pressure.
- The equipment you are using can't deliver enough water flow. Check the hoses, maybe they are too small.

Temperature Fault: The temperature of the cooling water or ambient temperature is too high. Colder cooling water will solve the problem (The generator trips at 37°C).

RPH: The phases on main electricity input are wrong. You must switch the phases.

10. Service and Maintenance

10.1 Daily control of hoses, cables and connections

Warning!

Every morning and before starting work with the RPR-1650 you should check all hoses, cables and connections for any leakage or damage. Do not use the equipment before damage is repaired.

10.2 Daily cleaning of RPR-1650


Danger!

Disconnect the electricity to RPR-1650 before the cleaning starts. The main generator, including all connections, cables and electrical circuits, contains high-frequent electric power with condensators which store the electricity. This can lead to electrical shock which can cause serious injury or death to people coming in contact with the source.

- Wash the equipment daily with lukewarm water and a soft detergent. DO NOT use high-pressure washing!
- Clean the wheels on the induction-head daily, both the track and the indicator tracks for the PLC-sensor. Scrape off remains of coating or paint and wash with lukewarm water and soft detergent

Track

Indicator-tracks on the inside



- Clean the induction head with a stiff brush (not a steel brush) and lukewarm water and soft detergent.

For service, repair and maintenance, contact your local RPR-dealer or RPR Technologies AS info@rprtech.com

11. Dealers and Servicing

Norway:

RPR Technologies

Rolighetsvegen 7c, 3933 Porsgrunn, Norway

Phone: +47 35 60 35 38

Fax: +47 67 43 00 57

Web: <http://www.rprtec.com>

Norspray AS

Contact: Roar Bråtane

Address: Gamle Forusvei 14c, 4033 Stavanger, Norway

Phone: +47 51 22 07 01

Fax: + 47 51 59 18 90

Web: <http://www.norspray.no>

USA:

Keizer Technologies, Inc

North American Sales

Contact: Judd Adcock

Address: 10908 South Pipeline Road, Euless, Texas 76040, USA

Phone: Tel: +01 817 685 7090

Fax: +01 817 685 9190

Web: <http://www.torbousa.com>

Peru/Chile

Consultores Marinos SAC

Av. Los Halcones 424, Lima-34, Peru

Tel: +511 99 834 2483

Contact: Javier A. Calmet Aranguren

France:

Plastocor-france S.A.S.

21, En Chaplerue, F-57000 Metz, France

Tel: +33 (0) 67 360 67 12

Fax: +33 (0) 38 779 46 86

Contact: Hubert Barth

German, BeNeLux and Austrian Sales

Oftec GmbH

Barbarastrasse 75-77, D-46282 Dorsten, Germany

Tel: +49 (0) 209 9592 144

Contact: Mr. Christian Streck

Spain:**Salvio Busquets, S.A.**

75-77, Les Corts, 10, 08249 Cabrera de Mar, Barcelona

Tel: +34 629 711 346

Contact: Mr. Alfred Busquets

Japan:**e-Energy Corporation**

7-19, Akasaka 1-chome, Minato-ku, Tokyo 107-0052, Japan

Tel: +81 3 5549 7771

Fax: +81 3 5549 7774

Contact: Wataru Nammoku

South Korea:**Mrs Kyung-Ja Kim**

1150 German Village, Mulgeon-ri, Samdong-myeon, Namhae-gun,
Kyeong-nam (668-841), South-Korea

Tel: +82 (0)55 867 1180

Fax: +82 (0)10 4621 5099

Contact: Mrs Kyung-Ja Kim

Taiwan:**TGC Technology Ltd**

6th Fl., 267 Tun Hwa South Road, Sec. 2 Taipei 10675, Taiwan

Tel: +886 2 2378 9331

Fax: +886 2 2378 8667

Contact: Carol Chen

Vietnam:**Vinashin Petroleum Investment & Transport**

Unit 210-211, 02nd Floor, Petro Vietnam Tower, No. 1-5 Le Duan Str,
Ben Nghe Ward, District 1, Ho Chi Minh City, Vietnam

Tel: +84 839 300 704

Fax: +84 839 300 706


Contact: Mr. Phan Minh Dung

Appendix 1: RPR-1650 Voltage Output / Speed Program 1

Voltage output (%)

Speedfactors

Powerfactors



Position 5: 100% (above 90% of 100% (90%) the "fast lightindicator" will twinkle slow, and above 100% it will twinkle fast)

Position 4: 90% (above 90% of 90% (81%) the "fast lightindicator" will twinkle slow, and above 90% it will twinkle fast)

Position 3: 80% (above 90% of 80% (72%) the "fast lightindicator" will twinkle slow, and above 80% it will twinkle fast)

Position 2: 70% (above 90% of 70% (63%) the "fast lightindicator" will twinkle slow, and above 70% it will twinkle fast)


Position 1: 60% (above 90% of 60% (54%) the "fast lightindicator" will twinkle slow, and above 60% it will twinkle fast)

below 45% the "slow lightindicator" will twinkle slow

below 40% the "slow lightindicator" will twinkle fast and after 3 seconds the power will shut off

Speed (m/min.)

Appendix 2: RPR-1650 Voltage Output / Speed Program 2




Powerfactors

Position 5: 100%, above 90% the "fast lightindicator" will twinkle slow and above 99% it will twinkle fast

below 5% higher then min. power the "slow lightindicator" will twinkle slow
 Min. Powerfactor, adjustable between 40, 45, 50, 55, 60, 65 and 70 %, at zero speed the "slow lightindicator" will twinkle fast and after 2 seconds the power will shut off



**the world's fastest,
safest and cleanest
method for removing
paint from steel surfaces**



www.rprtech.com